

07.5—500 Checking and adjusting closing angle (dwell angle) and firing point

Closing angle (dwell angle)

Normal coil ignition (S)

Closing angle (dwell angle)

Change between idle and 3000/min

Testing and adjusting value at idle¹⁾

39—42°

max. $\pm 3^\circ$

¹⁾ When installing new breaker points, adjust closing angle (dwell angle) to $42 \pm 1^\circ$.

Transistorized ignition system (J) (USA)

Identification: blue ignition coil, two pre-resistors and transistorized switchgear.

Closing angle (dwell angle)

Change between idle and 3000/min

Testing and adjusting value at idle²⁾

30—40°

max. $\pm 3^\circ$


²⁾ When installing new and when adjusting used breaker points, adjust closing angle (dwell angle) to $34 \pm 1^\circ$.

Firing point

Ignition distributor Bosch no.	Adjusting value of firing point	Test value Ignition adjustment without vacuum			Vacuum adjustment after		Installation value of ignition distributor at starting speed
	with vacuum at idle	1500/min	3000/min	4500/min	"retard" at idle	"advance" at 4500/min (total)	without vacuum
S 1976							
0 231 309 001	TDC	11–17°	26–30°	26–30°	4–6°	8–12° (34–42°)	5° before TDC
J 1976							
0 231 311 001	7° before TDC	10–16°	26–33°	29–35°	—	—	7° before TDC
USA 1973/74							
0 231 310 002	4° after TDC	13–17°	31–35°	37–41°	9–13°	—	7° before TDC
USA 1975/76							
0 231 311 001	7° before TDC	10–16°	26–33°	29–35°	—	—	7° before TDC


Special tools

Digital tester



001 589 54 21 00

Connecting cable



000 589 04 90 00

Intermediate plug (adaptor)



000 589 72 63 00

Trigger



000 589 71 63 00

Conventional tools


Revolution counter, stroboscope, closing angle (dwell angle) measuring instrument

Checking and adjusting closing angle (dwell angle)

- 1 Measure closing angle (dwell angle) at idle speed.
- 2 Measure closing angle (dwell angle) change between idle speed and 3000/min, max. change $\pm 3^\circ$.
- 3 Adjust closing angle (dwell angle), if required or replace breaker points (07.5–505).

With used breaker points, the closing angle (dwell angle) can be adjusted only with transistorized ignition.

Large dwell angle — small point spacing
Small dwell angle — large point spacing



Checking and adjusting firing point

- 4 Measure firing point with stroboscope or digital tester at specified speed with or without vacuum.

5 Loosen ignition distributor and set adjusting value of firing point by turning ignition distributor.

Screw down ignition distributor and check firing point.

6 Check centrifugal and vacuum adjustment of ignition distributor. For this purpose, run through specified test values with or without vacuum adjustment.

